

## Disc Top Gym Tile Installation Instructions

Disc Top Gym Tile is 19 5/8" x 19 5/8" tile that features an attractive raised disc pattern. Disc Top is designed for easy installation in interior applications without adhesives. The following will make your installation of Disc Top Gym Tile quick and easy:

- ☑ Rubber mallet
- ☑ Utility knife to cut the tiles to shape
- ☑ Tape measure
- ☑ Chalk line
- ☑ Knee pads (optional for comfort)

1. Disc Top Gym Tile must be site conditioned at room temperature for 24 hours prior to installation. During this period, room temperature must be maintained at 70° F +/- 5° (21° C +/- 3° C).
2. Start by calculating the center of the room
3. Lay tiles from the center working towards the walls as per Diagram A. Use a rubber mallet to interlock the tiles into place. First lay the full tiles then proceed with the trimmed tiles around the walls.
4. The tiles can be easily cut with a sharp utility knife or electric saw.
5. A space of 1/4" (6mm) expansion gap should be left at the walls and any other obstacles such as pillars and extremely heavy equipment.

